

Thermometers

Thermometer Cases

Slotted brass thermometer cases with a ring. Ideal for dipping.



Product No	Thermometer length-mm
10880/01	152
10880/02	305

Min/Max Thermometers

Speediset

Economical minimum/maximum thermometer with Celsius and Fahrenheit scales, that resets by simply swivelling to a vertical position on its hinged mounting bracket



Product No	Range (°C)	Range (°F)
10891/01	-30 to +50	-20 to +120

Digital Thermometer



Encased in high grade ABS, these thermometers are suitable for wall-mounting or bench standing. They have two sensors, one in the unit itself and a second remote, and water-resistant sensor connected via a three metre lead. Current temperatures are simultaneously displayed in separate 12mm LCD windows.

Maximum/Minimum temperatures can be recalled at the touch of a button and reset if required. Temperatures can be displayed in either Centigrade or Fahrenheit.

Model 11440/02 incorporates a user-set sonic alarm which sounds should the set Min/Max values be exceeded. It also displays the current time (12-hour clock). Require one AAA battery.

Min/Max Thermometers

Product No	Description
11440/01	Min/max thermometer
11440/02	Min/max thermometer with alarm & clock
10993/01	1.5 volt AAA battery

Temperature range

Inside	-10 to 60°C (50 to 140°F)
Remote	-50 to 70°C (-58 to 158°F)
Accuracy	±1.0°C (±1.8°F) in range 0 to 50°C, otherwise ±2.0°C
Resolution	0.1°C/F

Constant Display

Product No **11360/01**

For maximum convenience, this thermometer constantly displays current, maximum and minimum temperatures. Either internal or remote temperatures can be selected in °C or °F.

Temperature range

Inside	0 to 50°C/32 to 122°F
Remote	-50 to 70°C/-58 to 158°F
Resolution	0 to 50°C/32 to 122°F

Digital Thermometers

Product No **11442/01**

An economically priced multi-purpose thermometer with a 120 x 3.5mm diameter stainless steel penetration probe. A special facility allows the displayed temperature to be 'frozen'

Specifications

Range	-50 to +150°C
Resolution	0.1z (from -20 to +150°C°)
Accuracy	<±1°C (from -10 to 100C°, otherwise ±2C°)
Battery life	5000 hours (approx.)

Checktemp

A range of digital, hand-held thermometers with rugged ABS housings. Indicating temperatures over a range from -50 to +150°C°, a simulation switch sends out a 0.0°C (±0.3°C°) signal which can then be confirmed on the display to ensure instrument accuracy. The probe utilises a high-tech NTC thermistor sensor which makes it possible to obtain extremely high accuracy in a very short period of time.

Specifications

Range	-50 to +150°C
Resolution	0.1°C
Accuracy	@ -20 to +90C° ±0.3C°
Typical EMC deviation	±0.3C°
Battery life (approx)	3000 hours

Checktemp C

Product No **10881/01**

Supplied with a 105mm, 3mm diameter stainless steel probe and is suitable for measurements in liquid, air and semi-solids.



Checktemp 1

Product No **10882/01**

Supplied with a 160mm, 3mm diameter stainless steel probe with a one metre cable. It is suitable for use in liquids, air and semi-solids.

